



Receiver/Tuner

Device Type	Brand Name	Subtotal																								
			1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24
Receiver/Tuner	Aiwa	3	010	040	047																					
Receiver/Tuner	Denon	24	025	031	032	044	048	049	061	062	064	065	069	070	071	074	075	076	079	088	092	093	094	096	106	107
Receiver/Tuner	Harman/ Kardon	4	002	067	090	086																				
Receiver/Tuner	JBL	1	002																							
Receiver/Tuner	JVC	3	028	029	054																					
Receiver/Tuner	Kenwood	11	013	014	017	018	023	027	038	042	056	081	091													
Receiver/Tuner	Marantz	1	095																							
Receiver/Tuner	Onkyo	22	020	024	036	039	041	055	059	063	066	068	072	073	077	078	080	082	083	084	085	087	089	097		
Receiver/Tuner	Panasonic	10	003	052	098	099	100	101	102	103	104	105														
Receiver/Tuner	Pioneer	6	009	019	021	045	046	058																		
Receiver/Tuner	Sony	10	000	001	004	005	006	007	008	012	016	034														
Receiver/Tuner	Technics	9	003	011	030	033	035	050	053	057	060															
Amplifier	Yamaha	2	037	043																						
Receiver	Yamaha	1	043																							
Receiver/Amplifier	Yamaha	2	026	037																						
Receiver/Tuner	Yamaha	5	015	022	026	037	051																			



Cable Box

Device Type	Brand Name	Subtotal	1	2	3
Cable Box	ABC	1	004		
Cable Box	Adelphia	1	008		
Cable Box	Contec	1	003		
Cable Box	GE	1	004		
Cable Box	Gemini	1	002		
Cable Box	General Instruments	3	001	004	010
Cable Box	Hamlin	1	007		
Cable Box	Hitachi	1	004		
Cable Box	Jerrold	2	001	004	
Cable Box	Motorola	2	011	012	
Cable Box	Oak	1	003		
Cable Box	Philips	1	002		
Cable Box	Proscan	1	004		
Cable Box	RCA	1	001		
Cable Box	Rembrandt	1	004		
Cable Box	Scientific Atlanta	3	005	006	008
Cable Box	Signature	1	004		
Cable Box	Sony	1	009		
Cable Box	TIME WARNER	1	013		
Cable Box	View Star	1	003		
CBL-DVR	Motorola	1	000		
CBL-DVR	Comcast	1	000		



DVD

Device Type	Brand Name	Subtotal	1	2	3	4	5	6	7	8	9
DVD	Apex	2	024	067							
DVD	BOSE	1	004								
DVD	Broksonic	2	002	068							
DVD	Clarion	1	005								
DVD	Classic	1	006								
DVD	Daewoo	2	051	087							
DVD	Denon	1	057								
DVD	Emerson	1	007								
DVD	Fisher	1	065								
DVD	Funai	1	008								
DVD	GE	1	059								
DVD	Go Video	2	077	099							
DVD	GPX	1	009								
DVD	Harman/Kardon	1	062								
DVD	Hitachi	3	052	069	085						
DVD	Irradio	1	010								
DVD	JVC	4	034	042	043	080					
DVD	Kenwood	1	063								
DVD	Konka	1	025								
DVD	Lasonic	1	011								
DVD	LG	1	061								
DVD	Magnavox	4	032	054	086	091					
DVD	Marantz	1	060								
DVD	Memorex	1	012								
DVD	Mintek	1	013								
DVD	Mitsubishi	1	049								



DVD	NAD	2	007	014										
DVD	Nakamichi	1	015											
DVD	Nexxtech	1	066											
DVD	Norcent	1	016											
DVD	Onkyo	1	056											
DVD	Oritron	1	017											
DVD	Panasonic	7	028	037	038	070	076	090	117					
DVD	Philips	4	041	045	071	082								
DVD	Pioneer	1	036											
DVD	Polaroid	1	088											
DVD	Qwestar	1	017											
DVD	RCA	6	029	040	047	072	079	093						
DVD	Sampo	1	018											
DVD	Samsung	3	031	078	094									
DVD	Sansui	2	019	073										
DVD	Sanyo	2	001	003										
DVD	Sharp	3	044	084	092									
DVD	Sherwood	1	020											
DVD	Sony	9	000	026	027	030	033	035	039	064	075			
DVD	Sylvania	2	053	091										
DVD	Teac	1	013											
DVD	Techwood	1	021											
DVD	Toshiba	7	023	032	046	048	074	081	089					
DVD	Yamaha	1	058											
DVD	Zenith	2	050	083										
DVD Recorder	Aspire	1	113											
DVD Recorder	Go Video	1	110											
DVD Recorder	Irradio	1	100											
DVD Recorder	Magnavox	1	108											
DVD Recorder	Panasonic	2	102	109										
DVD Recorder	Philips	4	100	103	107	111								
DVD Recorder	Pioneer	2	105	106										
DVD Recorder	Samsung	1	104											
DVD Recorder	Sony	4	095	096	097	101								



DVD Recorder	Toshiba	1	098																	
DVD Recorder	Yamaha	1	112																	
DVD-DVR	Pioneer	1	116																	
DVD-DVR	RCA	1	114																	
DVD-DVR	Toshiba	1	115																	
Portable DVD	Audiovox	1	055																	
Portable DVD	CyberHome	1	022																	



SAT

	Device Type	Brand Name	Subtotal	1	2	3	4
Digital Network Recorder		Sony	1	026			
SAT		DIRECTV	2	010	028		
SAT		DISH Network	4	000	030	031	032
SAT		Philips	1	009			
SAT		Pioneer	1	021			
SAT		GE	1	014			
SAT		Hughes	2	003	028		
SAT		Hughes Network System	1	028			
SAT		JVC	1	029			
SAT		Mitsubishi	1	001			
SAT		Panasonic	2	002	006		
SAT		RCA	3	014	019	022	
SAT		Samsung	2	005	020		
SAT		Sony	4	004	015	017	018
SAT		Toshiba	2	007	014		
SAT		Zenith	1	008			
SAT-DVR		Hughes	1	023			
SAT-DVR		Philips	2	023	027		
SAT-DVR		RCA	2	023	024		
SAT-DVR		Samsung	1	023			
SAT-DVR		Sony	1	026			
Satellite Receiver/Recorder		Philips	1	016			
Satellite Receiver/Recorder		RCA	1	012			
Satellite Receiver/Recorder		Sony	1	011			
Satellite Receiver/Recorder		Zenith	1	013			



TV

Device Type	Brand Name	Subtotal	1	2	3	4	5	6	7	8	9	10	11
HDTV	Apex	1	073										
HDTV	Daewoo	1	075										
HDTV	Hitachi	1	069										
HDTV	Mitsubishi	1	068										
HDTV	Panasonic	1	071										
HDTV	Sony	1	070										
HDTV	Sampo	1	053										
HDTV	Zenith	1	076										
HT Projector	Sharp	1	065										
LCD TV	Benq	1	045										
LCD TV	ESA	1	043										
LCD TV	NET-TV	1	046										
LCD TV	Panasonic	2	038	039									
LCD TV	Philips	1	036										
LCD TV	Polaroid	1	042										
LCD TV	Samsung	4	031	032	033	035							
LCD TV	Sharp	2	028	034									
LCD TV	Sony	1	030										
LCD TV	Sylvania	1	043										
LCD TV	Toshiba	1	029										
LCD TV	Viewsonic	2	041	044									
LCD TV	Zenith	1	040										
LCD TV Monitor	Magnavox	1	037										
LCD TV/Tuner	Philips	1	036										
Plasma Display	Acer	1	052										
Plasma Display	Pioneer	1	057										



Plasma Display	Samsung	1	047																
PLASMA TV	Gateway	1	053																
PLASMA TV	Hitachi	1	054																
PLASMA TV	LG	1	055																
PLASMA TV	NET-TV	1	053																
PLASMA TV	ViewSonic	1	053																
PLASMA TV	Zenith	1	049																
Plasma TV Monitor	Fujitsu	1	050																
Plasma TV Monitor	NEC	1	056																
Plasma TV Monitor	Pioneer	1	072																
Plasma TV Monitor	Toshiba	1	051																
Projection HDTV	Sharp	1	074																
Projection Monitor	Pioneer	1	064																
Projection TV	Hitachi	1	061																
Projection TV	JVC	1	062																
Projection TV	LG	1	066																
Projection TV	Magnavox	1	063																
Projection TV	Mitsubishi	1	060																
Projection TV	Samsung	1	047																
Projection TV	Sony	1	059																
Projection TV	Toshiba	1	058																
Projection TV	Zenith	1	067																
TV	Admiral	2	048	020															
TV	Adventura	1	021																
TV	Aiko	1	008																
TV	Aiwa	1	110																
TV	Akai	1	001																
TV	Alleron	1	011																
TV	Amtron	1	010																
TV	Anam National	2	002	010															
TV	AOC	3	003	004	005														
TV	Apex	1	089																
TV	Audiovox	1	010																
TV	Belcor	1	003																



TV	Bell & Howell	2	048	012																
TV	Bradford	1	010																	
TV	Brockwood	1	003																	
TV	Broksonic	1	090																	
TV	Candle	4	003	005	006	021														
TV	Celebrity	1	001																	
TV	Citizen	7	003	005	006	008	010	016	019											
TV	Colortyme	2	003	005																
TV	Concerto	2	003	005																
TV	Contec/Cony	2	007	010																
TV	Craig	1	010																	
TV	Crown	2	010	014																
TV	Curtis Mathes	6	003	005	012	016	019	025												
TV	CXC	1	010																	
TV	Daewoo	6	003	004	005	008	019	109												
TV	Daytron	3	003	005	019															
TV	Dimensia	1	025																	
TV	Dumont	2	003	017																
TV	Electroband	1	001																	
TV	Electrohome	4	001	002	003	005														
TV	Emerson	9	003	005	007	009	010	011	012	019	023									
TV	Envision	2	003	005																
TV	Fisher	1	012																	
TV	Fujitsu	1	011																	
TV	Funai	2	010	011																
TV	Futuretech	1	010																	
TV	GE	6	002	003	005	013	025	101												
TV	Gibraltar	2	003	017																
TV	Goldstar	5	003	004	005	007	019													
TV	Grunpy	2	010	011																
TV	Hallmark	2	003	005																
TV	Harvard	1	010																	
TV	Hisense	1	026																	
TV	Hitachi	5	003	005	007	024	111													



TV	IMA	1	010																
TV	Infinity	1	014																
TV	Janeil	1	021																
TV	JBL	1	014																
TV	JC Penney	8	003	004	005	006	013	016	019	025									
TV	JCB	1	001																
TV	Jensen	2	003	005															
TV	JVC	3	007	013	107														
TV	Kawasho	3	001	003	005														
TV	Kenwood	2	003	005															
TV	Kloss Novabeam	2	010	021															
TV	KTV	2	010	019															
TV	LG	1	004																
TV	Loewe	1	014																
TV	Logik	1	048																
TV	Luxman	2	003	005															
TV	LXI	4	005	012	014	025													
TV	Magnavox	6	003	005	006	014	088	106											
TV	Majestic	1	048																
TV	Marantz	3	003	005	014														
TV	Megatron	1	005																
TV	Memorex	4	048	004	005	012													
TV	MGA	3	003	004	005														
TV	Midland	3	013	017	019														
TV	Mitsubishi	3	003	004	005														
TV	Montgomery Ward	1	048																
TV	Motorola	2	002	020															
TV	MTC	4	003	004	005	016													
TV	Multitech	1	010																
TV	Multivision	1	015																
TV	NAD	2	005	024															
TV	NEC	4	002	003	004	005													
TV	Nikko	2	005	008															
TV	NTC	1	008																



TV	Onwa	1	010																	
TV	Optimus	1	024																	
TV	Optonica	1	020																	
TV	Orion	2	009	023																
TV	Panasonic	9	002	013	014	083	091	102	112	113	114									
TV	Philco	7	002	003	004	005	006	007	014											
TV	Philips	7	002	003	006	007	014	092	105											
TV	Pilot	2	003	019																
TV	Pioneer	3	003	005	024															
TV	Portland	5	003	004	005	008	019													
TV	Price Club	1	016																	
TV	Prima	1	027																	
TV	Prism	1	013																	
TV	Proscan	1	025																	
TV	Proton	3	003	005	007															
TV	Pulsar	2	003	017																
TV	Quasar	3	002	013	102															
TV	Radio Shack	2	012	025																
TV	Radio Shack/Realistic	6	003	005	007	010	012	019												
TV	RCA	9	002	003	004	005	025	078	086	093	104									
TV	Realistic	2	012	025																
TV	Runco	1	017																	
TV	Sampo	3	003	005	019															
TV	Samsung	8	003	004	005	007	016	019	087	098										
TV	Sansui	3	023	081	094															
TV	Sanyo	2	003	012																
TV	Scotch	1	005																	
TV	Scott	6	003	005	007	009	010	011												
TV	Sears	6	003	005	011	012	022	025												
TV	Sharp	8	003	005	007	019	020	079	085	099										
TV	Shogun	1	003																	
TV	Signature	1	048																	
TV	Simpson	1	006																	
TV	Sony	2	000	001																



TV	Soundesign	5	003	005	006	010	011							
TV	Squareview	1	022											
TV	SSS	2	003	010										
TV	Starlite	1	010											
TV	Supre-Macy	1	021											
TV	Supreme	1	001											
TV	Sylvania	7	003	005	006	014	084	095	103					
TV	Symphonic	2	010	022										
TV	Tandy	1	020											
TV	Tatung	1	002											
TV	Technics	1	013											
TV	Techwood	3	003	005	013									
TV	Teknika	11	048	003	004	005	006	007	008	010	011	016	019	
TV	TMK	2	003	005										
TV	Toshiba	6	012	016	082	096	097	100						
TV	Totevision	1	019											
TV	Vidtech	3	003	004	005									
TV	Viking	1	021											
TV	Wards	7	048	003	004	005	011	014	025					
TV	Yamaha	3	003	004	005									
TV	Zenith	7	048	003	017	018	077	080	108					



VCR

Device Type	Brand Name	Subtotal	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15
Digital Network Recorder	Sony	1	111														
DVR	Panasonic	1	109														
DVR	RCA	1	112														
DVR	RePlay	1	110														
DVR	Tivo	1	112														
DVR-PVR	Tivo	1	113														
DVR-PVR	Philips	1	113														
VCR	Philips	1	078														
VCR	Admiral	1	023														
VCR	Adventura	1	012														
VCR	Aiko	1	013														
VCR	Aiwa	2	012	083													
VCR	Akai	2	029	022													
VCR	American High	1	010														
VCR	Apex	1	087														
VCR	Asha	1	005														
VCR	Audio Dynamics	2	001	002													
VCR	Audiovox	1	006														
VCR	Beaumark	2	004	005													
VCR	Bell & Howell	1	003														
VCR	Broksonic	1	004														
VCR	Calix	1	006														
VCR	Candle	5	005	006	007	008	009										
VCR	Canon	1	010														
VCR	Capehart	1	021														
VCR	Carver	1	018														



VCR	CCE	2	013	017															
VCR	Citizen	6	005	006	007	008	009	013											
VCR	Colortyme	1	001																
VCR	Colt	1	017																
VCR	Craig	4	005	006	011	017													
VCR	Curtis Mathes	6	001	005	008	009	010	025											
VCR	Cybernex	1	005																
VCR	Daewoo	7	007	012	013	021	056	082	097										
VCR	Daytron	1	021																
VCR	DBX	2	001	002															
VCR	Dimensia	1	025																
VCR	Dynatech	1	012																
VCR	Electrohome	2	006	014															
VCR	Electroponic	1	006																
VCR	Emerson	6	004	006	007	010	012	014											
VCR	Fisher	2	003	011															
VCR	Fuji	2	029	010															
VCR	Funai	2	012	026															
VCR	Garrard	1	012																
VCR	GE	4	005	010	025	072													
VCR	Go Video	3	066	088	106														
VCR	Goldstar	3	001	006	009														
VCR	Gradiente	1	012																
VCR	Harley Davidson	1	012																
VCR	Harman/Kardon	1	001																
VCR	Harwood	1	017																
VCR	Headquarter	1	003																
VCR	Hi-Q	1	011																
VCR	Hitachi	4	016	022	084	095													
VCR	Instant Replay	1	010																
VCR	JC Penney	10	001	002	003	004	005	006	010	016	017	018							
VCR	JCL	1	010																
VCR	Jensen	2	016	022															
VCR	JVC	15	001	002	003	009	022	034	039	046	049	050	051	054	055	080	091		



VCR	Kenwood	6	001	002	003	008	009	022											
VCR	KLH	1	017																
VCR	Kodak	2	006	010															
VCR	LG	1	006																
VCR	Lloyd's	1	012																
VCR	Logik	1	017																
VCR	LXI	1	006																
VCR	Magnavox	7	010	018	020	047	079	096	104										
VCR	Magnin	1	006																
VCR	Marantz	7	001	002	003	008	009	010	018										
VCR	Marta	1	006																
VCR	Matsushita	1	010																
VCR	MEI	1	010																
VCR	Memorex	10	003	005	006	010	011	012	020	023	027	067							
VCR	MGA	1	014																
VCR	MGN Technology	1	005																
VCR	Midland	1	015																
VCR	Minolta	1	016																
VCR	Mitsubishi	4	014	016	035	061													
VCR	Montgomery Ward	1	023																
VCR	Motorola	2	010	023															
VCR	MTC	1	005																
VCR	Multitech	5	005	008	012	015	017												
VCR	NEC	6	001	002	003	008	009	022											
VCR	Nikko	1	006																
VCR	Noblex	1	005																
VCR	Olympus	1	010																
VCR	Optimus	2	006	023															
VCR	Optonica	1	019																
VCR	Orion	1	027																
VCR	Panasonic	10	000	010	032	040	058	073	074	075	086	099							
VCR	Pentax	2	008	016															
VCR	Pentex Research	1	009																
VCR	Philco	2	010	018															



VCR	Philips	6	010	018	019	037	078	093	108										
VCR	Philips Magnavox	1	037																
VCR	Pilot	1	006																
VCR	Pioneer	2	002	016															
VCR	Portland	2	008	021															
VCR	Proscan	3	025	064	065														
VCR	Protec	1	017																
VCR	Pulsar	1	020																
VCR	Quarter	1	003																
VCR	Quartz	1	003																
VCR	Quasar	3	010	068	074														
VCR	Radio Shack	2	006	019															
VCR	Radio Shack/Realistic	9	003	005	006	010	011	012	014	019	023								
VCR	Radix	1	006																
VCR	Randex	1	006																
VCR	RCA	12	005	010	016	025	028	041	059	062	063	077	090	102					
VCR	Realistic	10	003	005	006	007	010	011	012	014	019	023							
VCR	Ricoh	1	024																
VCR	Runco	1	020																
VCR	Samsung	7	005	007	015	069	089	103	107										
VCR	Sanky	2	020	023															
VCR	Sansui	3	002	022	027														
VCR	Sanyo	3	003	005	011														
VCR	Scott	2	004	007															
VCR	Sears	5	003	006	010	011	016												
VCR	Sharp	8	014	019	023	030	038	070	094	101									
VCR	Shintom	2	029	017															
VCR	Shogun	1	005																
VCR	Signature	1	023																
VCR	Singer	3	010	017	024														
VCR	Sony	9	029	031	033	036	043	052	053	060	085								
VCR	STS	1	010																
VCR	Sylvania	5	010	012	018	076	100												
VCR	Symphonic	2	012	026															



VCR	Tandy	1	003																
VCR	Tashiko	1	006																
VCR	Tatung	1	022																
VCR	Teac	2	012	022															
VCR	Technics	1	010																
VCR	Teknika	3	006	010	012														
VCR	TMK	1	005																
VCR	Toshiba	9	007	016	044	045	057	071	092	098	105								
VCR	Totevision	2	005	006															
VCR	Unitech	1	005																
VCR	Vector Research	4	001	002	007	008													
VCR	Victor	1	002																
VCR	Video Concepts	4	001	002	007	008													
VCR	Videosonic	1	005																
VCR	Wards	11	005	006	007	010	011	012	014	016	017	019	023						
VCR	White Westinghouse	1	026																
VCR	XR-1000	3	010	012	017														
VCR	Yamaha	5	001	002	003	009	022												
VCR	Zenith	6	029	020	024	042	048	081											



DVD/VCR COMBO

Device Type	Brand Name	Subtotal	DVD	VCR
DVD/VCR Combo	Apex	2	088	087
DVD/VCR Combo	Daewoo	2	087	097
DVD/VCR Combo	Go Video	4	077	088
DVD/VCR Combo			099	106
DVD/VCR Combo	Hitachi	2	085	095
DVD/VCR Combo	JVC	2	080	091
DVD/VCR Combo	Magnavox	2	086	096
DVD/VCR Combo	Panasonic	2	076	086
DVD/VCR Combo	Philips	2	082	093
DVD/VCR Combo	RCA	2	079	090
DVD/VCR Combo	Samsung	4	078	089
DVD/VCR Combo			104	107
DVD/VCR Combo	Sharp	2	084	094
DVD/VCR Combo	Sony	2	075	085
DVD/VCR Combo	Toshiba	4	081	092
DVD/VCR Combo			098	105



TV/DVD/VCR Combo

Device Type	Brand Name	Subtotal	TV	VCR	DVD
TV/DVD/VCR Combo	Magnavox	3	088	104	091
TV/DVD/VCR Combo	RCA	3	086	102	093
TV/DVD/VCR Combo	Samsung	3	087	103	094
TV/DVD/VCR Combo	Sharp	3	085	101	092
TV/DVD/VCR Combo	Sylvania	3	084	100	091
TV/DVD/VCR Combo	Toshiba	3	082	098	089



TV/DVD Combo

Device Type	Brand Name	Subtotal	TV	DVD
TV/DVD Combo	Apex	2	089	067
TV/DVD Combo	Broksonic	2	090	068
TV/DVD Combo	Hitachi	2	061	069
TV/DVD Combo	Philips	2	092	071
TV/DVD Combo	RCA	2	093	072
TV/DVD Combo	Sansui	2	094	073
TV/DVD Combo	Sylvania	2	095	053
TV/DVD Combo	Toshiba	4	096	074
TV/DVD Combo			097	074



TV/VCR Combo

Device Type	Brand Name	Subtotal	TV	VCR
TV/VCR Combo	Aiwa	2	110	083
TV/VCR Combo	GE	2	101	072
TV/VCR Combo	Hitachi	2	111	084
TV/VCR Combo	JVC	2	107	080
TV/VCR Combo	Magnavox	2	106	079
TV/VCR Combo	Philips	2	105	078
TV/VCR Combo	Quasar	2	102	074
TV/VCR Combo	RCA	2	104	077
TV/VCR Combo	Samsung	2	098	069
TV/VCR Combo	Sharp	2	099	070
TV/VCR Combo	Sylvania	2	103	076
TV/VCR Combo	Toshiba	2	100	071
TV/VCR Combo	Zenith	2	108	081



TV/VCR/Tuner Combo

Device Type	Brand Name	Subtotal	TV	VCR	TUNER
TV/VCR/Tuner Combo	Panasonic	15	102 073	099	
			112 074	102	
			102 074	100	
			102 074	101	
			112 074	103	



TV/DVD/VCR/Tuner Combo

Device Type	Brand Name	Subtotal	TV	VCR	DVD	TUNER
TV/DVD/VCR/Tuner Combo	Panasonic	8	083	099	090	104
			113	075	117	105



TV/DVD/Tuner Combo

Device Type	Brand Name	Subtotal	TV	DVD	TUNER
TV/DVD/Tuner Combo	Panasonic	1	091	070	098