



TV Device

Device Type	Brand Name	Subtotal																																					
			1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37
Digital TV	Sony	1	041																																				
HT Projector	Epson	3	036	040	046																																		
HT Projector	Hitachi	1	052																																				
HT Projector	Mitsubishi	1	060																																				
HT Projector	Philips	1	058																																				
HT Projector	Sanyo	1	033																																				
HT Projector	Sharp	10	034	037	044	048	049	050	053	054	055	056																											
HT Projector	Sony	3	032	039	045																																		
HT Projector	Toshiba	5	038	047	057	059	061																																
LCD Projection TV	Sharp	1	024																																				
LCD Projection TV	Sony	1	007																																				
LCD Projection TV	Toshiba	1	023																																				
LCD TV	Bush	1	009																																				
LCD TV	LG	4	012	013	016	018																																	
LCD TV	Panasonic	2	014	017																																			
LCD TV	Philips	2	004	279																																			
LCD TV	Samsung	5	002	003	011	015	021																																
LCD TV	Sharp	4	010	019	020	022																																	
LCD TV	Sony	1	005																																				
LCD TV	Toshiba	1	008																																				
LCD TV/Radio Tuner Combo	Philips	1	279																																				

























**VCR Device**

Device Type	Brand Name	Subtotal																		
			1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18
DVD/VCR Combo	JVC	2 075 083																		
DVD/VCR Combo	LG	1 068																		
DVD/VCR Combo	Philips	1 074																		
DVD/VCR Combo	Samsung	2 052 063																		
DVD/VCR Combo	Sharp	1 080																		
TV/VCR Combo	Grundig	1 064																		
TV/VCR Combo	Samsung	1 081																		
VCR	Akiba	1 020																		
VCR	Akura	1 020																		
VCR	Alba	3 005 007 020																		
VCR	Allorgan	1 033																		
VCR	Ambassador	1 007																		
VCR	Anitech	1 020																		
VCR	ASA	2 011 012																		
VCR	Asuka	3 011 012 020																		
VCR	Baird	1 005																		
VCR	Basic Line	3 005 007 020																		
VCR	Baur	2 012 015																		
VCR	Bestar	2 005 007																		
VCR	Black Panther Line	1 005																		
VCR	Blaupunkt	5 012 013 014 015 018																		
VCR	Bondstec	1 007																		
VCR	Bush	3 005 020 022																		
VCR	Catron	1 007																		
VCR	Cimline	1 020																		
VCR	Clatronic	1 007																		
VCR	Condor	2 005 007																		



VCR	Crown	3	005	007	020															
VCR	Cybermaxx	1	039																	
VCR	Daewoo	5	005	007	016	019	039													
VCR	Dansai	1	020																	
VCR	Daytron	1	005																	
VCR	De Graaf	1	012																	
VCR	Decca	1	012																	
VCR	Dual	1	012																	
VCR	Dumont	1	012																	
VCR	Elin	1	009																	
VCR	Elta	1	020																	
VCR	ESC	1	005																	
VCR	Etzuko	1	020																	
VCR	Ferguson	2	018	025																
VCR	Finlandia	1	012																	
VCR	Finlux	2	012	029																
VCR	FIRST LINE	4	011	016	020	029														
VCR	Formenti/Phoenix	1	012																	
VCR	Frontech	1	007																	
VCR	GBC	2	007	020																
VCR	GEC	1	012																	
VCR	Geloso	1	020																	
VCR	General	1	007																	
VCR	General Technic	2	014	033																
VCR	GoldHand	1	020																	
VCR	GoldStar	1	011																	
VCR	Goodmans	6	005	007	009	011	020	021												
VCR	Granada	3	003	012	018															
VCR	Grandin	4	005	007	011	020														
VCR	Grundig	9	012	013	015	018	020	022	023	040	064									
VCR	Hanseatic	2	011	012																
VCR	HCM	2	020	022																
VCR	Hinari	2	020	022																
VCR	Hitachi	2	012	058																
VCR	Hypson	1	020																	



VCR	Impego	1	007																
VCR	Inno Hit	5	005	007	009	012	020												
VCR	Innovation	3	014	033	034														
VCR	Interbuy	1	011																
VCR	Interfunk	1	012																
VCR	Irradio	2	011	020															
VCR	ITT	1	024																
VCR	ITV	2	005	011															
VCR	JVC	8	024	025	026	027	028	051	075	083									
VCR	Kaisui	1	020																
VCR	Karcher	1	012																
VCR	Kendo	3	005	007	016														
VCR	Korpel	1	020																
VCR	Lenco	1	005																
VCR	Leyco	1	020																
VCR	LG	3	011	054	068														
VCR	Lifetec	4	014	033	034	039													
VCR	Loewe	2	014	017															
VCR	Loewe Opta	3	011	012	018														
VCR	Logik	2	009	020															
VCR	Lumatron	2	005	019															
VCR	Luxor	2	021	029															
VCR	Magnum	1	034																
VCR	Manesth	2	016	020															
VCR	Marantz	3	012	018	021														
VCR	Matsui	1	011																
VCR	Mediator	1	012																
VCR	Medion	4	014	033	034	039													
VCR	Memorex	2	003	011															
VCR	Memphis	1	020																
VCR	Metz	4	014	015	017	018													
VCR	Micromaxx	4	014	033	034	039													
VCR	Microstar	4	014	033	034	039													
VCR	Minerva	2	015	018															
VCR	Mitsubishi	3	012	025	029														



VCR	Multitech	3	007	012	020															
VCR	National	2	013	014																
VCR	NEC	1	025																	
VCR	Neckermann	1	012																	
VCR	NEI	1	012																	
VCR	Nesco	1	020																	
VCR	Nikkai	1	007																	
VCR	Nokia	2	003	009																
VCR	Nordmende	2	024	025																
VCR	Oceanic	1	003																	
VCR	Onkyo	1	033																	
VCR	Osaki	2	011	020																
VCR	Otto Versand	1	012																	
VCR	Palladium	3	011	018	020															
VCR	Panasonic	11	013	014	017	036	044	047	062	070	076	079	082							
VCR	Philips	18	000	002	012	018	023	024	037	041	043	050	055	059	065	066	069	071	073	074
VCR	Phonola	1	012																	
VCR	Pioneer	2	012	025																
VCR	Portland	2	005	007																
VCR	Profex	1	020																	
VCR	Proline	1	022																	
VCR	Pye	1	012																	
VCR	Quelle	3	012	015	018															
VCR	Radiola	1	012																	
VCR	Rex	1	024																	
VCR	RFT	2	007	012																
VCR	Roadstar	4	005	009	011	020														
VCR	Saba	1	024																	
VCR	Saisho	1	020																	
VCR	Salora	1	029																	
VCR	Samsung	6	009	033	034	052	063	081												
VCR	Samurai	1	007																	
VCR	Sansui	1	025																	
VCR	SBR	1	012																	
VCR	Schneider	6	005	007	011	012	016	020												



VCR	SEG	2	009	020															
VCR	SEI-Sinudyne	1	012																
VCR	Sentra	1	007																
VCR	Sentron	1	020																
VCR	Sharp	5	003	004	021	057	080												
VCR	Shintom	1	020																
VCR	Shivaki	1	011																
VCR	Siemens	3	011	015	018														
VCR	Silva	1	011																
VCR	Sinudyne	1	012																
VCR	Solavox	1	007																
VCR	Sonoko	1	005																
VCR	Sonolor	1	003																
VCR	Sontec	1	011																
VCR	Sony	13	006	008	010	031	032	035	038	045	046	048	067	072	077				
VCR	Standard	1	005																
VCR	Sunwood	1	020																
VCR	Tandberg	1	015																
VCR	Tashiko	1	003																
VCR	Tatung	1	012																
VCR	TCM	4	014	033	034	039													
VCR	Tec	1	007																
VCR	Technics	2	013	014															
VCR	Telefunken	4	024	025	026	030													
VCR	Tenosal	1	020																
VCR	Tensai	2	011	020															
VCR	Tevion	4	014	033	034	039													
VCR	Thomson	6	001	024	025	026	049	053											
VCR	Tivo Hdd	1	038																
VCR	Tokai	2	011	020															
VCR	Tonsai	1	020																
VCR	Toshiba	11	012	016	024	029	042	056	060	061	078	084	085						
VCR	Towada	1	020																
VCR	Towika	1	020																
VCR	TVA	1	007																





VCR	Uher	1	011																
VCR	Unitech	1	009																
VCR	United Quick Star	1	005																
VCR	Universum	5	011	012	015	018	023												
VCR	Victor	2	025	026															
VCR	Videon	2	014	033															
VCR	Weltblick	1	011																
VCR	Yamishi	1	020																
VCR	Yokan	1	020																
VCR	Yoko	4	007	009	011	020													



DVD Device

Device Type	Brand Name	Subtotal	1	2	3	4	5	6	7	8	9	10	11
CD	Innovation	1 031											
CD	Lifetec	1 031											
CD	Magnum	1 031											
CD	Medion	1 031											
CD	Micromaxx	1 031											
CD	Microstar	1 031											
CD	TCM	1 031											
CD	Tevion	1 031											
DVD	Aiwa	2 022	108										
DVD	Akai	1 016											
DVD	Alba	1 068											
DVD	Apex	1 034											
DVD	Brandt	1 054											
DVD	Bush	3 069	076	115									
DVD	Classic	1 028											
DVD	CyberHome	2 047	073										
DVD	Daewoo	3 003	004	005									
DVD	Daytek	2 048	070										
DVD	Denon	1 033											
DVD	Denver	1 026											
DVD	DK Digital	1 074											
DVD	Dmtech	1 001											
DVD	Elta	2 013	027										
DVD	Emerson	1 020											
DVD	Fisher	1 023											
DVD	Go Video	1 015											
DVD	Goodmans	1 100											



DVD	Grundig	2	017	025										
DVD	Harmon/Kardon	1	039											
DVD	Hitachi	7	015	031	082	090	104	109	116					
DVD	Innovation	1	018											
DVD	JVC	5	010	058	062	075	079							
DVD	Kenwood	1	037											
DVD	LG	4	020	053	056	091								
DVD	Life	1	018											
DVD	Lifetec	1	018											
DVD	Loewe	2	017	114										
DVD	Marantz	2	024	101										
DVD	MBO	1	040											
DVD	Medion	2	002	018										
DVD	Micromaxx	1	018											
DVD	Microstar	1	018											
DVD	Mitsubishi	1	014											
DVD	Mustek	3	028	045	113									
DVD	NAD	1	038											
DVD	Nakamichi	1	042											
DVD	Onkyo	1	019											
DVD	Oritron	1	018											
DVD	Panasonic	1	067											
DVD	Philips	11	000	011	017	024	049	071	083	086	089	097	101	
DVD	Philips Magnavox	1	011											
DVD	RCA	1	029											
DVD	Saba	1	054											
DVD	Sampo	1	030											
DVD	Samsung	8	015	052	060	064	088	093	095	111				
DVD	Sanyo	1	084											
DVD	Schneider	4	001	002	018	117								
DVD	Scott	1	065											
DVD	SEG	4	036	055	080	117								
DVD	Sharp	2	038	078										
DVD	Sherwood	1	035											
DVD	Shinco	1	029											



DVD	Skymaster	2	027	028									
DVD	Sony	10	012	050	051	057	066	072	081	085	102	105	
DVD	TCM	1	018										
DVD	Tevion	1	018										
DVD	Thomson	10	008	009	044	054	059	098	103	106	107	112	
DVD	Toshiba	4	011	046	094	096							
DVD	Wharfedale	1	021										
DVD	Yamaha	1	032										
DVD	Yamakawa	1	041										
DVD	Zenith	1	020										
DVD Recorder	JVC	1	077										
DVD Recorder	Philips	4	061	063	092	099							
DVD/VCR Combo	Bush	1	076										
DVD/VCR Combo	Hitachi	1	082										
DVD/VCR Combo	Philips	1	089										
DVD/VCR Combo	Samsung	3	064	088	095								
HTIB	DK Digital	1	074										
HTIB	Mustek	1	113										
HTIB	Thomson	1	103										
Portable DVD	Bush	1	087										
Portable DVD	Yukai	1	110										
TV	Thomson	3	006	007	043								
TV/DVD Combo	Bush	1	115										
TV/DVD Combo	Goodmans	1	100										
TV/DVD Combo	Thomson	1	107										



CD Device

Device Type	Brand Name	Subtotal													
			1	2	3	4	5	6	7	8	9	10			
CD	Adcom	1	120												
CD	Aiwa	6	121	122	123	194	195	201							
CD	Akai	3	124	125	126										
CD	Alba	1	127												
CD	Arcam	1	179												
CD	Bestar	1	128												
CD	BSR	1	129												
CD	Bush	1	130												
CD	Carrera	1	131												
CD	Condor	1	129												
CD	Denon	3	132	133	197										
CD	Dual	2	120	203											
CD	Elta	3	152	153	185										
CD	Emerson	2	120	128											
CD	Fisher	1	134												
CD	Genexxa	7	128	135	136	137	138	139	140						
CD	GoldStar	1	131												
CD	Goodmans	2	141	142											
CD	Grundig	2	177	179											
CD	Harmon/Kardon	2	143	144											
CD	Hitachi	3	120	145	146										
CD	Innovation	7	178	182	183	184	185	186	187						
CD	JVC	1	147												
CD	Kenwood	4	134	148	149	150									
CD	LG	1	131												
CD	Lifetec	7	178	182	183	184	185	186	187						
CD	Linn	1	179												



CD	Luxman	1	151																			
CD	Magnavox	1	177																			
CD	Magnum	7	178	182	183	184	185	186	187													
CD	Marantz	3	154	177	179																	
CD	Matsui	2	155	179																		
CD	Medion	7	178	182	183	184	185	186	187													
CD	Memorex	3	120	128	140																	
CD	Meridian	1	179																			
CD	Micromaxx	7	178	182	183	184	185	186	187													
CD	Micromega	1	179																			
CD	Microstar	7	178	182	183	184	185	186	187													
CD	Mission	1	179																			
CD	NAD	2	135	180																		
CD	Naim	1	179																			
CD	Nakamichi	2	156	157																		
CD	Onkyo	5	118	158	159	160	199															
CD	Panasonic	1	130																			
CD	Philips	4	119	161	177	179																
CD	Philips CD-V	1	118																			
CD	Pioneer	3	137	140	191																	
CD	Proton	1	179																			
CD	Quad	1	179																			
CD	Realistic	3	120	128	138																	
CD	Roadstar	2	161	162																		
CD	Rotel	1	179																			
CD	Saba	1	120																			
CD	SAE	1	179																			
CD	Sansui	6	119	163	164	165	177	179														
CD	Schneider	2	129	179																		
CD	Scott	1	128																			
CD	Sharp	5	136	166	167	168	200															
CD	Sherwood	1	198																			
CD	Skymaster	1	196																			
CD	Sony	10	135	169	170	171	181	188	189	190	192	193										
CD	Tandberg	1	179																			



CD	TCM	7	178	182	183	184	185	186	187				
CD	Teac	1	202										
CD	Technics	1	173										
CD	Telefunken	1	120										
CD	Tevion	7	178	182	183	184	185	186	187				
CD	Thomson	1	120										
CD	Toshiba	2	174	175									
CD	Universum	1	179										
CD	Victor	1	147										
CD	Victor Research	1	131										
CD	Yamaha	3	166	172	176								
CD	Yorx	1	162										



**SAT Device**

Device Type	Brand Name	Subtotal													
			1	2	3	4	5	6	7	8	9	10	11	12	
SAT	Akai	1 027													
SAT	Alba	1 081													
SAT	Allsat	1 027													
SAT	Amstrad	1 022													
SAT	Asat	1 027													
SAT	Astra	1 082													
SAT	Astro	2 005 006													
SAT	Blaupunkt	1 005													
SAT	Brain Wave	1 007													
SAT	Brandt	1 030													
SAT	BT Satellite	1 030													
SAT	Bush	2 008 081													
SAT	Chaparral	1 017													
SAT	Chess	2 024 031													
SAT	CityCom	1 081													
SAT	Clatronic	1 007													
SAT	Connexions	2 004 009													
SAT	Daeryung	1 004													
SAT	Diskxpress	1 009													
SAT	DNT	2 004 027													
SAT	Echostar	2 004 031													
SAT	Elta	1 027													
SAT	Emme Esse	1 008													
SAT	Ep Sat	1 081													
SAT	Eurodec	1 041													
SAT	Ferguson	4 008 010 041 081													
SAT	Finlandia	1 081													





SAT	Finlux	2	081	082															
SAT	Finnsat	1	041																
SAT	FTE	1	013																
SAT	Fuba	3	004	005	027														
SAT	Goodmans	1	081																
SAT	Granada	1	082																
SAT	Grundig	7	003	005	008	012	026	040	081										
SAT	Hanseatic	1	016																
SAT	Hantor	1	007																
SAT	Hirschmann	2	005	024															
SAT	Hisawa	1	007																
SAT	Hitachi	2	008	081															
SAT	Huth	1	007																
SAT	Innovation	3	016	031	032														
SAT	ITT Nokia	3	008	081	082														
SAT	ITT/Nokia	1	009																
SAT	Johansson	1	007																
SAT	Kathrein	10	005	006	013	014	015	017	025	027	043	044							
SAT	Kosmos	1	013																
SAT	Kreismeyer	1	005																
SAT	Leng	1	007																
SAT	Lenson	1	011																
SAT	Lifesat	3	016	031	032														
SAT	Lifetec	3	016	031	032														
SAT	Luxor	1	082																
SAT	Lyonnaise	1	041																
SAT	Macab	1	041																
SAT	Manhattan	2	008	081															
SAT	Marantz	1	027																
SAT	Maspro	3	008	017	081														
SAT	Matsui	1	030																
SAT	MB	1	016																
SAT	Medion	3	016	031	032														
SAT	Mega	1	027																
SAT	Metronic	1	049																



SAT	Metz	1	005																	
SAT	Micromaxx	3	016	031	032															
SAT	Microstar	3	016	031	032															
SAT	Minerva	1	005																	
SAT	Mitsubishi	3	005	030	081															
SAT	Morgan's	1	027																	
SAT	Multichoice	1	040																	
SAT	Multistar	1	013																	
SAT	Multitec	2	031	032																
SAT	Navex	1	007																	
SAT	Neuhaus	1	011																	
SAT	Nokia	4	008	009	081	082														
SAT	Nordmende	4	010	025	041	081														
SAT	Novis	1	007																	
SAT	Okano	1	013																	
SAT	Otto Versand	1	005																	
SAT	Pace	4	005	008	018	081														
SAT	Palcom	1	011																	
SAT	Panasonic	2	008	081																
SAT	Panda	1	081																	
SAT	Philips	12	003	008	012	018	019	026	027	029	038	039	042	081						
SAT	Phonotrend	1	081																	
SAT	Polsat	1	041																	
SAT	Predki	1	007																	
SAT	Promax	1	081																	
SAT	Quelle	1	005																	
SAT	Quiero	1	041																	
SAT	Radiola	1	027																	
SAT	Radix	2	004	047																
SAT	RFT	1	027																	
SAT	Saba	2	008	010																
SAT	Sabre	1	081																	
SAT	Sagem	1	041																	
SAT	Salora	1	082																	
SAT	Satcom	1	016																	



SAT	Satec	1	008											
SAT	SatPartner	1	007											
SAT	Schneider	2	031	032										
SAT	Schwaiger	3	014	016	032									
SAT	Seemann	1	004											
SAT	SEG	4	007	016	022	050								
SAT	Siemens	1	005											
SAT	Skymaster	11	016	023	024	031	032	033	034	035	036	037	045	
SAT	Skymax	1	027											
SAT	SR	1	010											
SAT	Starland	1	031											
SAT	Starring	1	007											
SAT	Strong	1	009											
SAT	Tandberg	1	041											
SAT	Tantec	3	008	011	081									
SAT	TCM	3	016	031	032									
SAT	TechniSat	5	004	011	020	021	046							
SAT	Telasat	1	016											
SAT	Telefunken	3	008	028	030									
SAT	Teleka	1	004											
SAT	Telesat	1	016											
SAT	Telestar	1	011											
SAT	Televés	1	081											
SAT	Tevion	3	016	031	032									
SAT	Thomson	8	001	002	010	028	030	041	062	081				
SAT	Thorn	2	008	081										
SAT	Tonna	1	081											
SAT	Triax	2	005	011										
SAT	Unitor	1	007											
SAT	Universum	1	005											
SAT	Variostat	1	005											
SAT	Ventana	1	027											
SAT	Visiosat	2	007	031										
SAT	VTech	1	019											
SAT	Wevasat	1	081											



SAT	Wewa	1	081																
SAT	Winersat	1	007																
SAT	Wisi	3	004	005	081														
SAT	Zehnder	5	013	014	022	048	049												
SAT-DVR	BSkyB	1	000																
SAT-DVR	Medion	1	060																
SAT-DVR	Pace	1	055																
Satellite	Alba	1	063																
Satellite	Amstrad	1	057																
Satellite	Anttron	1	063																
Satellite	Astro	1	063																
Satellite	AudioTon	1	063																
Satellite	Boca	4	064	066	071	080													
Satellite	BSkyB	1	057																
Satellite	Cambridge	1	064																
Satellite	Exator	1	063																
Satellite	FTE	1	064																
Satellite	Grundig	1	057																
Satellite	Hirschmann	1	061																
Satellite	Humax	2	054	056															
Satellite	JOK	1	065																
Satellite	Kathrein	2	053	063															
Satellite	KR	1	063																
Satellite	Kyostar	1	063																
Satellite	Lasat	1	064																
Satellite	Metronic	1	063																
Satellite	Morgan's	1	064																
Satellite	Nokia	2	074	075															
Satellite	Octagon	1	063																
Satellite	Pace	1	057																
Satellite	Panasonic	1	057																
Satellite	Philips	1	063																
Satellite	Preisner	1	064																
Satellite	Radix	3	058	068	077														
Satellite	Rainbow	1	063																



Satellite	Saba	1	065																
Satellite	Schacke	1	063																
Satellite	SEG	4	067	072	076	079													
Satellite	Siemens	1	064																
Satellite	Sony	1	052																
Satellite	Strong	1	069																
Satellite	TechniSat	3	051	070	078														
Satellite	Teleciel	1	063																
Satellite	Teleka	1	063																
Satellite	Visiosat	1	065																
Satellite	V-Tech	1	065																
Satellite	Wisi	2	065	073															
Satellite	Zodiac	1	063																
Satellite Receiver	Hauppauge	1	059																



**Cable Box Device**

Device Type	Brand Name	Subtotal	1	2	3	4	5	6
Cable Box	Alcatel	2	024	025				
Cable Box	Amstrad	1	015					
Cable Box	Arcon	1	015					
Cable Box	Axis	1	015					
Cable Box	Cabletime	6	001	002	003	018	019	021
Cable Box	Clyde Cablevision	1	004					
Cable Box	Cryptovision	1	005					
Cable Box	Fidelity	1	015					
Cable Box	Filmnet Cablecrypt	2	006	020				
Cable Box	Filmnet Comcrypt	1	006					
Cable Box	Finlux	1	008					
Cable Box	France Telecom	2	022	023				
Cable Box	GEC	1	004					
Cable Box	Gooding	1	007					
Cable Box	Grundig	2	015	007				
Cable Box	Hirschmann	1	008					
Cable Box	ITT Nokia	1	008					
Cable Box	Jerrold	2	014	016				
Cable Box	JVC	1	007					
Cable Box	Macab	1	023					
Cable Box	Maspro	1	007					
Cable Box	Matsui	1	007					
Cable Box	Minerva	1	007					
Cable Box	M-Net	1	020					
Cable Box	Movie Time	1	013					
Cable Box	Nokia	1	008					
Cable Box	Palladium	1	007					



Cable Box	Philips	4	000	007	022	023		
Cable Box	Pioneer	3	015	009	010			
Cable Box	PVP Stereo Visual Matrix	1	016					
Cable Box	Sagem	1	023					
Cable Box	SAT	1	015					
Cable Box	Scientific Atlanta	2	011	012				
Cable Box	Tele +1	1	006					
Cable Box	Tele+1	1	020					
Cable Box	Telepiu	1	020					
Cable Box	United Cable	1	016					
Cable Box	Universum	2	007	008				
Cable Box	Videoway	1	017					
Cable Box	Visiopass	3	008	022	023			
Cable Box	Wittenberg	1	015					



**AUDIO Device**

Device Type	Brand Name	Subtotal	1	2	3	4	5	6	7
Amplifier	Denon	1 003							
Amplifier	JVC	1 006							
Amplifier	Marantz	2 021 022							
Amplifier	Pioneer	3 008 019 020							
Amplifier	Sony	5 002 004 018 023 024							
Amplifier	Teac	2 017 025							
Amplifier	Yamaha	7 007 011 026 027 028 029 030							
HTIB	Aiwa	1 033							
HTIB	DK Digital	1 032							
HTIB	LG	1 034							
HTIB	Sanyo	1 035							
Receiver	Pioneer	1 031							
Receiver/Amplifier	Yamaha	2 029 030							
Receiver/Tuner	Aiwa	2 033 047							
Receiver/Tuner	Denon	5 005 014 039 046 048							
Receiver/Tuner	DK Digital	1 032							
Receiver/Tuner	JVC	1 010							
Receiver/Tuner	Kenwood	1 043							
Receiver/Tuner	LG	1 034							
Receiver/Tuner	Marantz	1 001							
Receiver/Tuner	Pioneer	1 031							
Receiver/Tuner	Sanyo	1 035							
Receiver/Tuner	Sony	7 000 015 036 040 041 042 044							
Receiver/Tuner	Teac	1 013							
Receiver/Tuner	Technics	2 037 049							
Receiver/Tuner	Thomson	1 009							
Receiver/Tuner	Yamaha	5 012 016 038 045 050							