



TV Device

Device Type	Brand Name	Subtotal	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27
Digital TV	Sony	1	038																										
HT Projector	Epson	3	033	037	043																								
HT Projector	Hitachi	1	049																										
HT Projector	Mitsubishi	1	056																										
HT Projector	Philips	1	054																										
HT Projector	Sanyo	1	030																										
HT Projector	Sharp	9	031	034	041	045	046	047	050	051	052																		
HT Projector	Sony	3	029	036	042																								
HT Projector	Toshiba	5	035	044	053	055	057																						
LCD Projection TV	Sharp	1	022																										
LCD Projection TV	Sony	1	006																										
LCD Projection TV	Toshiba	1	021																										
LCD TV	Bush	1	008																										
LCD TV	LG	4	010	011	014	016																							
LCD TV	Panasonic	2	012	015																									
LCD TV	Philips	1	004																										
LCD TV	Samsung	4	002	003	013	019																							
LCD TV	Sharp	4	009	017	018	020																							
LCD TV	Sony	1	005																										
LCD TV	Toshiba	1	007																										
Plasma Display	Hitachi	2	023	026																									
Plasma Display	Panasonic	1	028																										



VCR Device

Device Type	Brand Name	Subtotal	1	2	3	4	5	6	7	8	9	10	11	12	13	14
DVD/VCR Combo	JVC	2	048	055												
DVD/VCR Combo	LG	1	041													
DVD/VCR Combo	Philips	1	047													
DVD/VCR Combo	Samsung	1	026													
DVD/VCR Combo	Sharp	1	052													
TV/VCR Combo	Grundig	1	037													
TV/VCR Combo	Samsung	1	053													
VCR	Alba	1	004													
VCR	ASA	2	009	010												
VCR	Asuka	2	009	010												
VCR	Baird	1	004													
VCR	Basic Line	1	004													
VCR	Baur	2	010	011												
VCR	Bestar	1	004													
VCR	Black Panther Line	1	004													
VCR	Blaupunkt	3	010	011	013											
VCR	Bush	2	004	015												
VCR	Condor	1	004													
VCR	Crown	1	004													
VCR	Daewoo	2	004	014												
VCR	Daytron	1	004													
VCR	De Graaf	1	010													
VCR	Decca	1	010													
VCR	Dual	1	010													
VCR	Dumont	1	010													
VCR	Elin	1	007													
VCR	ESC	1	004													



VCR	Ferguson	2	013	017															
VCR	Finlandia	1	010																
VCR	Finlux	1	010																
VCR	FIRST LINE	1	009																
VCR	Formenti/Phoenix	1	010																
VCR	GEC	1	010																
VCR	GoldStar	1	009																
VCR	Goodmans	3	004	007	009														
VCR	Granada	3	003	010	013														
VCR	Grandin	2	004	009															
VCR	Grundig	6	010	011	013	015	016	037											
VCR	Hanseatic	2	009	010															
VCR	HCM	1	015																
VCR	Hinari	1	015																
VCR	Hitachi	2	010	032															
VCR	Inno Hit	3	004	007	010														
VCR	Interbuy	1	009																
VCR	Interfunk	1	010																
VCR	Irradio	1	009																
VCR	ITV	2	004	009															
VCR	JVC	5	017	018	025	048	055												
VCR	Karcher	1	010																
VCR	Kendo	1	004																
VCR	Lenco	1	004																
VCR	LG	3	009	028	041														
VCR	Loewe	1	012																
VCR	Loewe Opta	3	009	010	013														
VCR	Logik	1	007																
VCR	Lumatron	2	004	014															
VCR	Marantz	2	010	013															
VCR	Matsui	1	009																
VCR	Mediator	1	010																
VCR	Memorex	2	003	009															
VCR	Metz	3	011	012	013														
VCR	Minerva	2	011	013															



VCR	Mitsubishi	2	010	017													
VCR	Multitech	1	010														
VCR	NEC	1	017														
VCR	Neckermann	1	010														
VCR	NEI	1	010														
VCR	Nokia	2	003	007													
VCR	Nordmende	1	017														
VCR	Oceanic	1	003														
VCR	Osaki	1	009														
VCR	Otto Versand	1	010														
VCR	Palladium	2	009	013													
VCR	Panasonic	7	012	019	022	036	043	049	054								
VCR	Philips	14	000	002	010	013	016	024	029	033	038	039	042	044	046	047	
VCR	Phonola	1	010														
VCR	Pioneer	2	010	017													
VCR	Portland	1	004														
VCR	Proline	1	015														
VCR	Pye	1	010														
VCR	Quelle	3	010	011	013												
VCR	Radiola	1	010														
VCR	RFT	1	010														
VCR	Roadstar	3	004	007	009												
VCR	Samsung	3	007	026	053												
VCR	Sansui	1	017														
VCR	SBR	1	010														
VCR	Schneider	3	004	009	010												
VCR	SEG	1	007														
VCR	SEI-Sinudyne	1	010														
VCR	Sharp	3	003	031	052												
VCR	Shivaki	1	009														
VCR	Siemens	3	009	011	013												
VCR	Silva	1	009														
VCR	Sinudyne	1	010														
VCR	Sonoko	1	004														
VCR	Sonolor	1	003														



VCR	Sontec	1	009																
VCR	Sony	8	005	006	008	020	021	040	045	050									
VCR	Standard	1	004																
VCR	Tandberg	1	011																
VCR	Tashiko	1	003																
VCR	Tatung	1	010																
VCR	Telefunken	1	017																
VCR	Tensai	1	009																
VCR	Thomson	4	001	017	023	027													
VCR	Tokai	1	009																
VCR	Toshiba	6	010	030	034	035	051	056											
VCR	Uher	1	009																
VCR	Unitech	1	007																
VCR	United Quick Star	1	004																
VCR	Universum	5	009	010	011	013	016												
VCR	Victor	1	017																
VCR	Weltblick	1	009																
VCR	Yoko	2	007	009															



DVD Device

Device Type	Brand Name	Subtotal																		
			1	2	3	4	5	6	7	8	9	10								
CD	Innovation	1	026																	
CD	Lifetec	1	026																	
CD	Magnum	1	026																	
CD	Medion	1	026																	
CD	Micromaxx	1	026																	
CD	Microstar	1	026																	
CD	TCM	1	026																	
CD	Tevion	1	026																	
DVD	Aiwa	2	019	090																
DVD	Alba	1	051																	
DVD	Brandt	1	037																	
DVD	Bush	3	052	059	097															
DVD	Classic	1	023																	
DVD	CyberHome	2	030	056																
DVD	Daewoo	3	003	004	005															
DVD	Daytek	2	031	053																
DVD	Denver	1	021																	
DVD	DK Digital	1	057																	
DVD	Dmtech	1	001																	
DVD	Elta	2	012	022																
DVD	Emerson	1	017																	
DVD	Fisher	1	020																	
DVD	Go Video	1	014																	
DVD	Goodmans	1	082																	
DVD	Hitachi	6	014	026	065	086	091	098												
DVD	Innovation	1	015																	
DVD	JVC	5	009	041	045	058	062													



DVD	LG	4	017	036	039	073															
DVD	Life	1	015																		
DVD	Lifetec	1	015																		
DVD	Loewe	1	096																		
DVD	Marantz	1	083																		
DVD	Medion	2	002	015																	
DVD	Micromaxx	1	015																		
DVD	Microstar	1	015																		
DVD	Mitsubishi	1	013																		
DVD	Mustek	3	023	028	095																
DVD	Onkyo	1	016																		
DVD	Oritron	1	015																		
DVD	Panasonic	1	050																		
DVD	Philips	9	000	010	032	054	066	069	072	079	083										
DVD	Philips Magnavox	1	010																		
DVD	RCA	1	024																		
DVD	Saba	1	037																		
DVD	Sampo	1	025																		
DVD	Samsung	8	014	035	043	047	071	075	077	093											
DVD	Sanyo	1	067																		
DVD	Schneider	4	001	002	015	099															
DVD	Scott	1	048																		
DVD	SEG	3	038	063	099																
DVD	Sharp	1	061																		
DVD	Shinco	1	024																		
DVD	Skymaster	2	022	023																	
DVD	Sony	10	011	033	034	040	049	055	064	068	084	087									
DVD	TCM	1	015																		
DVD	Tevion	1	015																		
DVD	Thomson	10	007	008	027	037	042	080	085	088	089	094									
DVD	Toshiba	4	010	029	076	078															
DVD	Wharfedale	1	018																		
DVD	Zenith	1	017																		
DVD Recorder	JVC	1	060																		
DVD Recorder	Philips	4	044	046	074	081															



DVD/VCR Combo	Bush	1	059										
DVD/VCR Combo	Hitachi	1	065										
DVD/VCR Combo	Philips	1	072										
DVD/VCR Combo	Samsung	3	047	071	077								
HTIB	DK Digital	1	057										
HTIB	Mustek	1	095										
HTIB	Thomson	1	085										
Portable DVD	Bush	1	070										
Portable DVD	Yukai	1	092										
TV	Thomson	1	006										
TV/DVD Combo	Bush	1	097										
TV/DVD Combo	Goodmans	1	082										
TV/DVD Combo	Thomson	1	089										



CD Device

Device Type	Brand Name	Subtotal							
			1	2	3	4	5	6	
CD	Adcom	1	102						
CD	Aiwa	6	103	104	105	161	162	167	
CD	Akai	3	106	107	108				
CD	Alba	1	109						
CD	Bestar	1	110						
CD	BSR	1	111						
CD	Bush	1	112						
CD	Carrera	1	113						
CD	Condor	1	111						
CD	Denon	3	114	115	164				
CD	Dual	2	102	169					
CD	Elta	2	132	133					
CD	Emerson	2	102	110					
CD	Fisher	1	116						
CD	Genexxa	6	110	117	118	119	120	121	
CD	GoldStar	1	113						
CD	Goodmans	2	122	123					
CD	Harmon/Kardon	1	124						
CD	Hitachi	3	102	125	126				
CD	Innovation	6	149	151	152	153	154	155	
CD	JVC	1	127						
CD	Kenwood	4	116	128	129	130			
CD	LG	1	113						
CD	Lifetec	6	149	151	152	153	154	155	
CD	Luxman	1	131						
CD	Magnum	6	149	151	152	153	154	155	
CD	Marantz	1	134						



CD	Matsui	1	135					
CD	Medion	6	149	151	152	153	154	155
CD	Memorex	3	102	110	121			
CD	Micromaxx	6	149	151	152	153	154	155
CD	Microstar	6	149	151	152	153	154	155
CD	NAD	2	117	150				
CD	Nakamichi	2	136	137				
CD	Onkyo	2	100	138				
CD	Panasonic	1	112					
CD	Philips	1	101					
CD	Philips CD-V	1	100					
CD	Pioneer	3	119	121	159			
CD	Realistic	3	102	110	120			
CD	Roadstar	1	139					
CD	Saba	1	102					
CD	Sansui	4	101	140	141	142		
CD	Schneider	1	111					
CD	Scott	1	110					
CD	Sharp	4	118	143	144	166		
CD	Sherwood	1	165					
CD	Skymaster	1	163					
CD	Sony	6	117	145	156	157	158	160
CD	TCM	6	149	151	152	153	154	155
CD	Teac	1	168					
CD	Telefunken	1	102					
CD	Tevion	6	149	151	152	153	154	155
CD	Thomson	1	102					
CD	Toshiba	2	146	147				
CD	Victor	1	127					
CD	Victor Research	1	113					
CD	Yamaha	1	148					
CD	Yorx	1	139					



SAT Device

Device Type	Brand Name	Subtotal												
			1	2	3	4	5	6	7	8	9			
SAT	Akai	1	022											
SAT	Allsat	1	022											
SAT	Amstrad	1	019											
SAT	Asat	1	022											
SAT	Astro	1	005											
SAT	Brain Wave	1	006											
SAT	Brandt	1	025											
SAT	BT Satellite	1	025											
SAT	Chaparral	1	015											
SAT	Chess	1	026											
SAT	Clatronic	1	006											
SAT	Connexions	2	004	007										
SAT	Daeryung	1	004											
SAT	Diskxpress	1	007											
SAT	DNT	2	004	022										
SAT	Echostar	2	004	026										
SAT	Elta	1	022											
SAT	Eurodec	1	034											
SAT	Ferguson	2	008	034										
SAT	Finnsat	1	034											
SAT	FTE	1	011											
SAT	Fuba	2	004	022										
SAT	Grundig	4	003	010	021	033								
SAT	Hanseatic	1	014											
SAT	Hantor	1	006											
SAT	Hisawa	1	006											
SAT	Huth	1	006											



SAT	Innovation	3	014	026	027									
SAT	ITT/Nokia	1	007											
SAT	Johansson	1	006											
SAT	Kathrein	7	005	011	012	013	015	022	036					
SAT	Kosmos	1	011											
SAT	Leng	1	006											
SAT	Lenson	1	009											
SAT	Lifesat	3	014	026	027									
SAT	Lifetec	3	014	026	027									
SAT	Lyonnaise	1	034											
SAT	Macab	1	034											
SAT	Marantz	1	022											
SAT	Maspro	1	015											
SAT	Matsui	1	025											
SAT	MB	1	014											
SAT	Medion	3	014	026	027									
SAT	Mega	1	022											
SAT	Micromaxx	3	014	026	027									
SAT	Microstar	3	014	026	027									
SAT	Mitsubishi	1	025											
SAT	Morgan's	1	022											
SAT	Multichoice	1	033											
SAT	Multistar	1	011											
SAT	Multitec	2	026	027										
SAT	Navex	1	006											
SAT	Neuhaus	1	009											
SAT	Nokia	1	007											
SAT	Nordmende	2	008	034										
SAT	Novis	1	006											
SAT	Okano	1	011											
SAT	Palcom	1	009											
SAT	Philips	9	003	010	016	021	022	024	031	032	035			
SAT	Polsat	1	034											
SAT	Predki	1	006											
SAT	Quiero	1	034											



SAT	Radiola	1	022																
SAT	Radix	2	004	039															
SAT	RFT	1	022																
SAT	Saba	1	008																
SAT	Sagem	1	034																
SAT	Satcom	1	014																
SAT	SatPartner	1	006																
SAT	Schneider	2	026	027															
SAT	Schwaiger	3	012	014	027														
SAT	Seemann	1	004																
SAT	SEG	4	006	014	019	041													
SAT	Skymaster	8	014	020	026	027	028	029	030	037									
SAT	Skymax	1	022																
SAT	SR	1	008																
SAT	Starland	1	026																
SAT	Starring	1	006																
SAT	Strong	1	007																
SAT	Tandberg	1	034																
SAT	Tantec	1	009																
SAT	TCM	3	014	026	027														
SAT	TechniSat	5	004	009	017	018	038												
SAT	Telasat	1	014																
SAT	Telefunken	2	023	025															
SAT	Teleka	1	004																
SAT	Telesat	1	014																
SAT	Telestar	1	009																
SAT	Tevion	3	014	026	027														
SAT	Thomson	7	001	002	008	023	025	034	053										
SAT	Triax	1	009																
SAT	Unitor	1	006																
SAT	Ventana	1	022																
SAT	Visiosat	2	006	026															
SAT	VTech	1	016																
SAT	Winersat	1	006																
SAT	Wisi	1	004																



SAT	Zehnder	4	011	012	019	040								
SAT-DVR	BSkyB	1	000											
SAT-DVR	Medion	1	051											
SAT-DVR	Pace	1	046											
Satellite	Alba	1	054											
Satellite	Amstrad	1	048											
Satellite	Anttron	1	054											
Satellite	Astro	1	054											
Satellite	AudioTon	1	054											
Satellite	Boca	3	055	057	061									
Satellite	BSkyB	1	048											
Satellite	Cambridge	1	055											
Satellite	Exator	1	054											
Satellite	FTE	1	055											
Satellite	Grundig	1	048											
Satellite	Hirschmann	1	052											
Satellite	Humax	2	045	047										
Satellite	JOK	1	056											
Satellite	Kathrein	2	044	054										
Satellite	KR	1	054											
Satellite	Kyostar	1	054											
Satellite	Lasat	1	055											
Satellite	Metronic	1	054											
Satellite	Morgan's	1	055											
Satellite	Octagon	1	054											
Satellite	Pace	1	048											
Satellite	Panasonic	1	048											
Satellite	Philips	1	054											
Satellite	Preisner	1	055											
Satellite	Radix	2	049	058										
Satellite	Rainbow	1	054											
Satellite	Saba	1	056											
Satellite	Schacke	1	054											
Satellite	SEG	1	062											
Satellite	Siemens	1	055											



Satellite	Sony	1	043								
Satellite	Strong	1	059								
Satellite	TechniSat	2	042	060							
Satellite	Teleciel	1	054								
Satellite	Teleka	1	054								
Satellite	Visiosat	1	056								
Satellite	V-Tech	1	056								
Satellite	Wisi	2	056	063							
Satellite	Zodiac	1	054								
Satellite Receiver	Hauppauge	1	050								



Cable Box Device

Device Type	Brand Name	Subtotal						
			1	2	3	4	5	6
Cable Box	Alcatel	2	022	023				
Cable Box	Amstrad	1	014					
Cable Box	Arcon	1	014					
Cable Box	Axis	1	014					
Cable Box	Cabletime	6	001	002	003	016	017	019
Cable Box	Clyde Cablevision	1	004					
Cable Box	Fidelity	1	014					
Cable Box	Filmnet Cablecrypt	2	005	018				
Cable Box	Filmnet Comcrypt	1	005					
Cable Box	Finlux	1	007					
Cable Box	France Telecom	2	020	021				
Cable Box	GEC	1	004					
Cable Box	Gooding	1	006					
Cable Box	Grundig	2	014	006				
Cable Box	Hirschmann	1	007					
Cable Box	ITT Nokia	1	007					
Cable Box	Jerrold	2	013	015				
Cable Box	JVC	1	006					
Cable Box	Macab	1	021					
Cable Box	Maspro	1	006					
Cable Box	Matsui	1	006					
Cable Box	Minerva	1	006					
Cable Box	M-Net	1	018					
Cable Box	Movie Time	1	012					
Cable Box	Nokia	1	007					
Cable Box	Palladium	1	006					
Cable Box	Philips	4	000	006	020	021		



Cable Box	Pioneer	3	014	008	009			
Cable Box	PVP Stereo Visual Matrix	1	015					
Cable Box	Sagem	1	021					
Cable Box	SAT	1	014					
Cable Box	Scientific Atlanta	2	010	011				
Cable Box	Tele +1	1	005					
Cable Box	Tele+1	1	018					
Cable Box	Telepiu	1	018					
Cable Box	United Cable	1	015					
Cable Box	Universum	2	006	007				
Cable Box	Visiopass	3	007	020	021			
Cable Box	Wittenberg	1	014					



AUDIO Devices

Device Type	Brand Name	Subtotal	1	2	3	4	5	6
Amplifier	Denon	1	003					
Amplifier	JVC	1	006					
Amplifier	Marantz	2	021	022				
Amplifier	Pioneer	3	008	019	020			
Amplifier	Sony	5	002	004	018	023	024	
Amplifier	Teac	2	017	025				
Amplifier	Yamaha	6	007	011	026	027	028	029
HTIB	Aiwa	1	032					
HTIB	DK Digital	1	031					
HTIB	LG	1	033					
HTIB	Sanyo	1	034					
Receiver	Pioneer	1	030					
Receiver/Amplifier	Yamaha	1	029					
Receiver/Tuner	Aiwa	1	032					
Receiver/Tuner	Denon	5	005	014	038	044	045	
Receiver/Tuner	DK Digital	1	031					
Receiver/Tuner	JVC	1	010					
Receiver/Tuner	Kenwood	1	041					
Receiver/Tuner	LG	1	033					
Receiver/Tuner	Marantz	1	001					
Receiver/Tuner	Pioneer	1	030					
Receiver/Tuner	Sanyo	1	034					
Receiver/Tuner	Sony	6	000	015	035	039	040	042
Receiver/Tuner	Teac	1	013					
Receiver/Tuner	Technics	2	036	046				
Receiver/Tuner	Thomson	1	009					
Receiver/Tuner	Yamaha	6	012	016	037	043	047	048